

Cluster Management and Maintenance

Rocks-A-Palooza II Lab Session





What We'll Be Doing

- Adding content to frontend's web site
- Discuss how to add new packages to compute nodes
- How to change configuration on compute node
- Adding an application to the compute nodes
- Discuss frontend and compute node partitioning
- Configuring additional ethernet interfaces on compute nodes



Add Content to the Frontend's Web Site





Adding Content to the Frontend's Web Site

- First, configure X
 # system-config-display
- Start the X window server
 # startx

ROCKS

Adding Content To Frontend's Web Site

Connect to web page

- # firefox <u>http://localhost/</u>
- Click on link at bottom of page:
 - Add content to this web site"
- Next screen you see 'Login/Password'
 - Login = 'admin'
 - Password = same as root password on frontend

	\wedge
\langle	ROCKS
	\bigvee

Adding Content To Frontend's Web Site

Click 'Write' tab

Dashboard	Write	Manage	Links	Presentation	Plugins	Users	Options	Logout (Administrator)
Write Post	Write Pa	age						
Wri	te Pos	t						
Title	9							
				_				

ROCKS

Adding Content To Frontend's Web Site

Write your 'post', then 'publish'

Title —															
Here's a	post														
Post															
	Quicktags:	str	ет	link	b-quote	del i	ns img	ul	ol	li code	more	page	Dict.	Close	Tag
rackBad	e <mark>k a URI</mark> : (Sej	parate	mult	iple U	RIs with	spaces.)								
'rackBao	<mark>sk a URI</mark> : (Sep	parate	mult	iple <u>U</u>	RIs with	spaces.) Save as	Draft	Sav	ve as I	Private	Publ	ish	Advar	nced Ed	iting

ROCKS

Adding Content To Frontend's Web Site

- View your new web site at:
 - http://localhost/





Add A New Package



ROCKS

Adding a New Package to the Distribution

- All packages are found under '/home/install'
- Put the new package in /home/install/contrib/4.1/i386/ RPMS
 - Where <arch> is 'i386', 'x86_64' or 'ia64'
- "Extend" an XML configuration file
- Rebind the distro:

cd /home/install

- # rocks-dist dist
- Apply the changes by reinstalling the compute nodes:
 - "shoot-node compute-0-0"

To add the package named "strace"

\$ cd /home/install/site-profiles/4.1/nodes

\$ cp skeleton.xml extend-compute.xml

In 'extend-compute.xml', change:

<package> <!-- insert your 1st package name here --> </package>

◆ To:

<package>strace</package>

Rebind the distro

This copies 'extend-compute.xml' into /home/ install/rocks-dist/.../build/nodes

cd /home/install
rocks-dist dist

Test the changes

- Generate a test kickstart file
 - # dbreport kickstart compute-0-0 > /tmp/ks.cfg
- You should see 'strace' under the '%packages' section

 When you are satisfied with the changes, reinstall a compute node

shoot-node compute-0-0



More on the Distro

- Rocks-dist looks for packages in:
 - "/home/install/ftp.rocksclusters.org"
 - RedHat and Rocks packages
 - "/home/install/contrib"
 - Pre-built 3rd party packages
 - "/usr/src/redhat/RPMS"
 - RedHat default location for 'built' packages
 - But, when building packages in Rocks source tree, packages are not placed here
 - The packages are placed local to the roll source code

More on the Distro

ROCKS

Any time you add a package to the distro, you must re-run "rocks-dist dist"

Red Hat

Enterprise

Red Hat

Updates

Rocks

Rocks

RPMS

 Rocks-dist binds all the found packages into a RedHat-compliant distribution Other

RPMS



More on the Distro



 Rocks-dist assembles a RedHat compliant distribution



Your Distro - Extending Rocks





Add an Application to the Compute Nodes





Default NFS Share

- By default, each node has access to NFS shared directory named '/share/apps'
- The actual location is on the frontend
 - '/export/apps' on the frontend is mounted on all nodes as '/ share/apps'
- Simply add directories and files to /export/apps on frontend



Default NFS Share - Example

On frontend:

cd /export/apps
touch myapp

On compute node:

ssh compute-0-0
cd /share/apps
ls
myapp

Default NFS Share Adding 'bonnie'

ROCKS

- Bonnie is a file system benchmark
 - See 'Introduction to Benchmarking' Lab
- We'll download the source and build it
 - On frontend:
 - # cd /share/apps
 - # mkdir benchmarks
 - # mkdir benchmarks/bonnie++
 - # cd benchmarks/bonnie++
 - # mkdir bin src
 - # cd src
 - # wget http://www.coker.com.au/bonnie++/bonnie++-1.03a.tgz



Adding bonnie

Build and install it:

tar -zxvf bonnie++-1.03a.tgz
cd bonnie++-1.03a
./configure --prefix=/share/apps/benchmarks/bonnie++
make ; make install

You can now run it on a compute node:

ssh compute-0-0
mkdir ~/output files

- # cd /share/apps/benchmarks/bonnie++/sbin/
- # ./bonnie++ -s 100 -r 50 -u root -n 0 -f -d ~/output_files



Package bonnie as an RPM

Checkout the Rocks development source tree

cd /export
mkdir src
cd src
cvs -d:pserver:anonymous@cvs.rocksclusters.org:/home/cvs/CVSROOT login
cvs -d:pserver:anonymous@cvs.rocksclusters.org:/home/cvs/CVSROOT checkout rocks-devel



Create a Benchmark Roll

- Use the 'template' roll to populate a skeleton 'benchmark' roll
 - # cd rocks/src/roll/
 # bin/make-roll-dir.py -n benchmark
- Create directory for bonnie
 - # cd benchmark/src
 - # mkdir bonnie



Get build files

- # cd bonnie
- # cp ../benchmark/Makefile .
- # cp ../benchmark/version.mk .

Get the source

wget http://www.coker.com.au/bonnie++/bonnie++-1.03a.tgz



Update version.mk to match source Change:

NAME = benchmark VERSION = 1 RELEASE = 1 TARBALL_POSTFIX = tgz

⇒ To:

NAME = bonnie++ VERSION = 1.03a RELEASE = 1 TARBALL_POSTFIX = tgz





make rpm

You see lots of output

The last line shows you where the resulting binary RPM is:

Wrote: /export/src/rocks/src/roll/benchmark/RPMS/i386/bonnie++-1.03a-1.i386.rpm



View the RPM contents

rpm -qlp /export/src/rocks/src/roll/benchmark/RPMS/i386/bonnie++-1.03a-1.i386.rpm

Which outputs:

/opt /opt/benchmark /opt/benchmark/bonnie++ /opt/benchmark/bonnie++/bin /opt/benchmark/bonnie++/bin/bon csv2html /opt/benchmark/bonnie++/bin/bon csv2txt /opt/benchmark/bonnie++/man /opt/benchmark/bonnie++/man/man1 /opt/benchmark/bonnie++/man/man1/bon csv2html.1 /opt/benchmark/bonnie++/man/man1/bon csv2txt.1 /opt/benchmark/bonnie++/man/man8 /opt/benchmark/bonnie++/man/man8/bonnie++.8 /opt/benchmark/bonnie++/man/man8/zcav.8 /opt/benchmark/bonnie++/sbin /opt/benchmark/bonnie++/sbin/bonnie++ /opt/benchmark/bonnie++/sbin/zcav © 2006 UC Regents

Copy the bonnie++ RPM so rocks-dist Can Find It

ROCKS

- All packages are found under '/home/install'
- Put bonnie++ RPM package in /home/install/ contrib/4.1/<arch>/RPMS

Where <arch> is 'i386', 'x86_64' or 'ia64'

cd /home/install/contrib/4.1/i386/RPMS
cp /export/src/rocks/src/roll/benchmark/RPMS/i386/bonnie++-1.03a-1.i386.rpm .

To add the package named "bonnie++"

\$ cd /home/install/site-profiles/4.1/nodes

\$ vi extend-compute.xml

In 'extend-compute.xml', change the section:

<package>strace</package>

◆ To:

<package>strace</package> <package>bonnie++</package>

Rebind the distro

This copies 'extend-compute.xml' into /home/ install/rocks-dist/.../build/nodes

cd /home/install
rocks-dist dist

Test the changes

- Generate a test kickstart file
 - # dbreport kickstart compute-0-0 > /tmp/ks.cfg
- You should see 'bonnie++' under the '%packages' section

 When you are satisfied with the changes, reinstall a compute node

shoot-node compute-0-0



Custom Partitioning





Default Frontend Partitioning

♦ 6 GB for /

- Applications
- Configuration files
- Log files
- 1 GB swap
- Rest of first drive is /export
 - Home directories
 - Rocks distribution



Modifying Frontend Partitioning

- Can only change during frontend installation
- Note: must have '/export'
 - /export is automatically mounted by all compute nodes

ROCKS

Default Compute Node Partitioning

- 6 GB for / on first disk
- 1 GB for swap on first disk
- Remainder of first disk
 - Partitioned as "/state/partition1"
- All non-root partitions are saved over reinstalls

Changing Size of Root and Swap on a Compute Node

ROCKS

- If just want to change size of root and swap, only need to change two variables
- Create the file "extend-auto-partition.xml"

cd /home/install/site-profiles/4.1/site-nodes/

- # cp skeleton.xml extend-auto-partition.xml
- Above the "<main>" section, add the two variables

<var name="Kickstart_PartsizeRoot" val="10000"/>
<var name="Kickstart_PartsizeSwap" val="2000"/>

- Above XML variables will create a 10 GB root partition and a 2 GB swap partition
- Rebind the distro (rocks-dist dist) and reinstall a compute node (shoot-node compute-0-0) © 2006 UC Regents

Specifying a New Partition Layout

- Only requirement is that '/' is "big enough"
- Create the file "extend-auto-partition.xml"
 - # cd /home/install/site-profiles/4.1/site-nodes/
 # cp skeleton.xml extend-auto-partition.xml
- In the "<main>" section, add (assumes disk name is 'hda'):

<main>

ROCKS

<part> / --size 9000 --ondisk hda </part>
<part> swap --size 1000 --ondisk hda </part>
<part> /mydata --size 1 --grow --ondisk hda </part>
</main>

 Rebind the distro (rocks-dist dist) and reinstall a compute node (shoot-node compute-0-0)



Specifying Software RAID

Create the file "extend-auto-partition.xml"
 # cd /home/install/site-profiles/4.1/site-nodes/
 # cp skeleton.xml extend-auto-partition.xml

In the "<main>" section, add:

<main>

<part> / --size 8000 --ondisk hda </part>
<part> swap --size 1000 --ondisk hda </part>
<part> raid.00 --size=10000 --ondisk hda </part>
<part> raid.01 --size=10000 --ondisk hdb </part>

<raid> /mydata --level=1 --device=md0 raid.00 raid.01 </raid> </main>

 Rebind the distro (rocks-dist dist) and reinstall a compute node (shoot-node compute-0-0)
 © 2006 UC Regents

39



Testing Changes

- Use:
 - "dbreport kickstart compute-0-0 > /tmp/ks.cfg"
- Should not see any output
 - That is, no error output
- The file "/tmp/ks.cfg" should contain your changes
 - Look for 'part' definitions towards the top of /tmp/ ks.cfg



Configuring Additional Ethernet Interfaces





Configuring 'eth1'

 If a compute node has a second ethernet NIC, use the command 'add-extra-nic' to assign it an IP address

add-extra-nic --if=<interface> --ip=<ip address> --netmask=<netmask>\
 --gateway=<gateway> --name=<host name> <compute node>



Configuring 'eth1' - Example

add-extra-nic --if=eth1 --ip=192.168.1.1 --netmask=255.255.255.0 \ --gateway=192.168.1.254 --name=fast-0-0 compute-0-0

- For compute-0-0, the above line sets the following values for 'eth1':
 - ⇒ IP address: 192.168.1.1
 - Name for above IP address: fast-0-0
 - Netmask: 255.255.255.0
 - ⇒ Gateway: 192.168.1.254



Configuring 'eth1'

To apply the change, reinstall the compute node

shoot-node compute-0-0